

## Cab Sliding Window

### Sliding Side Window Replacement



**WARNING:** Use extreme care when handling glass!

#### Sliding Window Removal

1. Remove the rivets around the sliding window.
2. Lift out the window.
3. Scrape off the old foam tape from the door panel.

#### Sliding Window Installation

1. Set the replacement window in the door frame and, from the inside, mark the rivet holes around the circumference of the replacement window.
2. Drill holes into the replacement window frame for the rivets.
3. Line the exterior opening on the door with foam tape.
4. Set the window into the opening.
5. Attach the window to the door frame with rivets.



*Sliding window in cab door*

**Utilimaster Customer Service**

**574-848-2200**

Email: [Parts@Utilimaster.com](mailto:Parts@Utilimaster.com)

**Window Cab Sliding, December 2014**

©Utilimaster Corp., 603 Earthway Boulevard, Bristol, Indiana 46507 USA